


Kassir uchun eslatma: QANDAY QILIB TOVAR QO'SHISH


1 Yon menyuni oching




2 "Boshqaruvchi" rejimiga kiring



3 Parolingizni kiriting




4 Yon menyudan "Katalog"ni oching




5 "Mening katalogim" bo'limini tanlang




6 Tovar kategoriyasini tanlang




7 Tovar tagkategoriyasini tanlang




8 + ni bosing



9 Qatorlarni to'ldiring



10 "OK" ni bosing, tovar qo'shilgan




Kassir uchun eslatma: QANDAY QILIB CHEK URISH


1 Kassirni tanlang



2 PIN-kodni kiriting



3 "+" ni bosib yoki shtrix kod skanerini ishlatib




4 Tovar nomini kiritib va uni tanlang




5 Miqdorni tanlang va "OK" ni bosib



6 Agar to'lov uchun yana tovar bo'lsa, "+" ni bosib




7 "To'lov uchun" tugmasini bosib



8 To'lov turini tanlang



9 Hisoblangan summani kiritib va "OK" ni bosib



10 Chek chop etilgandan so'ng oynani yoping

